

Maintenance and cleaning tips



The front covers of our juicers are comprised of polycarbonate and ABS models.For this reason, we advise not cleaning them in the dishwasher to prevent scratches or defects

- We advise using protective gloves to handle our juicers.
- Cleaning the juice extraction system and front cover at least once a day is advisable.
- Do not forget to regularly check the peel containers.
- It is not necessary to use specialized products.
- All parts can be washed in the dishwasher (it is advisable to clean the front cover by hand).





Clean the following components at least once a day:

Juice extraction area:

- o Juice extraction tray
- o Blade
- o Cups
- o Filter tray and filter
- o F ront cover
- o Chutes/containers
- o Stainl. steel machine front

Clean weekly or twice a week when required:

Feeder:

• Machine top

o Feed ramp

The machines must be cleaned and disinfected as frequently as indicated above. In this process, first remove all the solid waste, and then clean and disinfect. The following types of products can be used to disinfect the machines:

Descaling detergents/disinfectants for food use: Used either by immersion (small parts) or sprayed (large parts and stainless-steel front of machine) in the concentration recommended by the manufacturer. Each product must be left to act for the time indicated, and then rinsed well to avoid contact of the juice with the product. These products usually have a very high pH, which, with time, may degrade the polycarbonate, so it is advisable not to exceed the product action times on transparent plastic parts.

Chlorinated disinfectant detergents for food use: Same use as the previous products. They can be used by immersion or sprayed, bearing in mind the time recommendations given by the manufacturer. Thoroughly rinse the parts treated before they come in contact with the juice again.

Another option can be solutions with domestic use (4% chlorine) or industrial use (10% chlorine) bleach. The necessary concentration for it to be effective at room temperature is 100 ppm, which means 2.5 ml of domestic bleach for every litre of water, or 1 ml of industrial bleach per litre of water.





1. With the machine stopped press the off button.



2. Extract the front cover.



Remove containers.

3.



4. Fit the blade protector.



5. Unscrew the nuts.



6. Extract the cups.



7. Remove the filter tray.



8. Unscrew the nuts.



Extract the juice

9. extraction system.





10. Remove the drip tray and grid.



1. Clean all parts with water and liquid detergent



2. Also suitable for dishwashers (Except front cover)





1. Fit the drip tray and grid.



2. Mount the juice extraction system



Screw the nuts.

3.



4. Fit the scraper with its shafts and insert them into the filter.



5. Place the scraper relief upwards.



6. Fit the filter tray.



7. Fit the cups.



8. Firmly screw the nuts.



9. Each container in the correct position in the groove.



10. Fit the front cover.